



LAWN & GARDEN

MODEL N° 65009

***OWNER'S MANUAL***

Keep this Identification Number in case you need to contact our Customer Service Department.

## REGISTER YOUR LIFETIME PRODUCT TODAY!

There are benefits to registering your Lifetime product. With our new online product registration form, it's fast and easy! Register with us at [www.lifetime.com](http://www.lifetime.com) and enjoy these great benefits:

- Receive exclusive money-saving offers from BuyLifetime.com, our online store, as well as NEW product notifications and special closeout promotions!
- In the unlikely event of a product recall or safety modification, we will notify you.
- Registering your product guarantees you warranty service. If you do not register your product, your warranty rights will not be diminished. But you will need to provide a sales receipt to verify your product purchase date before warranty service will be provided.

### LIFETIME'S PROMISE TO YOU:

*Maintaining your privacy is our long-standing policy at Lifetime. And you can rest assured that Lifetime will not sell or provide your personal data to other third parties, or allow them to use your personal data for their own purposes.*

We invite you to read our privacy policy at [www.lifetime.com](http://www.lifetime.com)

**REGISTER today!**

### **\*\*U.S. and Canada customers ONLY\*\***

IF ASSISTANCE IS NEEDED,

## **DO NOT CONTACT THE STORE!**

**CALL OUR CUSTOMER SERVICE DEPARTMENT at 1 (800) 225-3865**

HOURS: 7:00 a.m. to 5:00 p.m. Monday through Friday (Mountain Standard Time)

\*\*Call, or visit our Web site for Saturday hours\*\*

\*\*For customers outside the U.S. or Canada, please contact the store for assistance.\*\*



## SAFETY INSTRUCTIONS



### **FAILURE TO FOLLOW THESE WARNINGS MAY RESULT IN SERIOUS INJURY OR PROPERTY DAMAGE AND WILL VOID WARRANTY.**

To ensure safety, do not attempt to assemble this product without following the instructions carefully. Check entire box and inside all packing material for parts and/or additional instruction material. Before beginning assembly, read the instructions and identify parts using the hardware identifier and parts list in this document. Proper and complete assembly, use and supervision are essential to reduce the risk of accident or injury.

- Do not use or store hot objects such as grills, blowtorches, welding equipment, etc. near the product.
- Two capable adults are required for assembly. (It is also recommended that a third adult function as an instruction reader.)

*Most injuries are caused by misuse and/or not following instructions. Use caution when using this product.*

## BEFORE BEGINNING ASSEMBLY



Keep the hardware bags and their contents separate. If any parts are missing, call our Customer Service Department.



***\*Two adults required to  
complete assembly\****  
(+ one adult suggested as an instruction reader)

**Only adults should set up the product. Do not allow children  
in the set-up area until assembly is complete.**



## TOOLS REQUIRED FOR THIS ASSEMBLY

Plain Screwdriver



(x1)

Needle-Nosed Pliers



(x1)

Socket Wrench  
w/7/16" Socket



(x1)

1/2" Wrench



(x1)

9/16" Wrench



(x2)

Safety Glasses



(1 pair for each  
person)

*Refer to the following areas throughout the instructions to assist in the assembly process:*

This area is located at the top, left-hand corner of the page and indicates which tools and hardware are needed to complete the assembly steps on a page.

**TOOLS AND HARDWARE REQUIRED FOR THIS PAGE**

This area is located at the top, right-hand corner of the page and shows an image of the product with shaded parts indicating which section is being assembled.

**SEC #**

This area is usually located in the bottom, left-hand corner of a step and indicates that special attention is needed to perform a particular part of a step.

*Note:*

These areas are usually located in the bottom, right-hand corner of a step and indicate that damage to the product or serious injury may occur if the caution or warning is not heeded.

**CAUTION****WARNING**

## PARTS & HARDWARE LIST

ID	Description	Quantity	✓	ID	Description	Quantity	✓
<b>Main Parts</b>				<b>BJU Tub-to-Axle/Frame Assembly Hardware</b>			
AVJ	Tub	1	<input type="checkbox"/>	AVU	5/16" Flat Washer	10	<input type="checkbox"/>
AMU	Wheel	2	<input type="checkbox"/>	AVV	5/16" x 1" Round Slotted Bolt	12	<input type="checkbox"/>
<b>BZZ 65009 Metal Parts Kit</b>				AVW	5/16" Lock Washer	12	<input type="checkbox"/>
AVK	Axle	1	<input type="checkbox"/>	AVX	5/16" Threaded Hex Nut	12	<input type="checkbox"/>
AVL	Handle Bars	1	<input type="checkbox"/>	AVY	Latch Spring	1	<input type="checkbox"/>
AVM	Axle Weldment	1	<input type="checkbox"/>	AAA	3/8" Nylock Nut	2	<input type="checkbox"/>
AVN	A-Frame	1	<input type="checkbox"/>	AWB	3/8" x 1 1/2" Spacer	2	<input type="checkbox"/>
AVO	Tongue	1	<input type="checkbox"/>	AWC	3/8" Plastic Flat Washer	2	<input type="checkbox"/>
<b>CLA 65009 Small Metal Parts Kit</b>				ABE	3/8" x 4" Hex Head Bolt	1	<input type="checkbox"/>
BJW	Tongue Mounting Bracket	1	<input type="checkbox"/>	AWD	Threaded Knob	1	<input type="checkbox"/>
AWA	Lock Bracket	1	<input type="checkbox"/>	AWE	3/8" x 5" Carriage Bolt	1	<input type="checkbox"/>
AVP	Wheel Spacing Bracket	2	<input type="checkbox"/>	BJX	3/8" x 4 1/4" Hex Head Bolt	1	<input type="checkbox"/>
AVZ	Latch Handle	1	<input type="checkbox"/>	<b>BJV Handle Bars-to-Tongue Assembly Hardware</b>			
AWF	Backing Plate	1	<input type="checkbox"/>	AWG	3/8" x 5" Hex Head Bolt	1	<input type="checkbox"/>
<b>BJS 65009 Yard Cart Hardware</b>				AWE	3/8" x 5" Carriage Bolt	1	<input type="checkbox"/>
<b>BJT Axle/Frame Assembly Hardware</b>				AAA	3/8" Nylock Nut	1	<input type="checkbox"/>
AVQ	Retainer Ring	2	<input type="checkbox"/>	AWH	Handle Bar Spacer	2	<input type="checkbox"/>
AVR	1/4" Nylon Insert Nut	8	<input type="checkbox"/>	AWI	Clevis Pin	1	<input type="checkbox"/>
AVS	1/4" x 1 1/2" U-Bolt	4	<input type="checkbox"/>	AWJ	Cotter Key	1	<input type="checkbox"/>
AVT	U-Bolt Mounting Plate	2	<input type="checkbox"/>	AWD	Threaded Knob	1	<input type="checkbox"/>

## HARDWARE IDENTIFIER

### AXLE/FRAME ASSEMBLY HARDWARE [BJT]

Hardware is actual size (Unless indicated otherwise\*)




**AVQ (x2)**  
Retainer Ring



**AVR (x8)**  
1/4" Nylon Insert Nut



**AVS (x4)\***  
1/4" x 1 1/2" U-Bolt



**AVT (x2)\***  
U-Bolt Mounting Plate

### TUB-TO-AXLE/FRAME ASSEMBLY HARDWARE [BJU]


Hardware is actual size (Unless indicated otherwise)



**AVU (x10)**  
5/16" Flat Washer



**AVV (x12)**  
5/16" x 1" Round Slotted Bolt



**AVY (x1)**  
Latch Spring



**AVW (x12)**  
5/16" Lock Washer



**AVX (x12)**  
5/16" Threaded Hex Nut

## HARDWARE IDENTIFIER

### TUB-TO-AXLE/FRAME ASSEMBLY HARDWARE [BJU] (CONTINUED)


Hardware is actual size (Unless indicated otherwise\*)



**AAA (x2)**  
3/8" Nylock Nut



**AWC (x2)**  
3/8" Plastic Flat Washer




**ABE (x1)**  
3/8" x 4" Hex Head Bolt




**AWB (x2)**  
3/8" x 1 1/2" Spacer



**AWE (x1)**  
3/8" x 5" Carriage Bolt




**AWD (x1)**  
Threaded Knob



**BIX (x1)**  
3/8" x 4 1/4" Hex Head Bolt

### HANDLE BARS-TO-TONGUE ASSEMBLY HARDWARE [BJV]

Hardware is actual size



**AWG (x1)**  
3/8" x 5" Hex Head Bolt



**AAA (x1)**  
3/8" Nylock Nut



**AWE (x1)**  
3/8" x 5" Carriage Bolt



**AWH (x2)**  
Handle Bar  
Spacer



**AWJ (x1)**  
Cotter Key



**AWI (x1)**  
Clevis Pin




**AWD (x1)**  
Threaded Knob

## PARTS IDENTIFIER

### MAIN PARTS

Parts are 5% of actual size




**AVJ (x1)**  
Tub




**AMU (x2)**  
Wheel

### 65009 METAL PARTS KIT [BZZ]


Parts are 5% of actual size (Unless indicated otherwise\*)



**AVM (x1)**  
Axle Weldment



**AVL (x1)**  
Handle Bars



**AVO (x1)**  
Tongue



**AVN (x1)**  
A-Frame




**AVK (x1)**  
Axle

### 65009 SMALL METAL PARTS KIT [CLA]


Parts are 5% of actual size (Unless indicated otherwise\*)



**BJW (x1)**  
Tongue Mounting Bracket



**AVZ (x1)\***  
Latch Handle



**AWF (x1)\***  
Backing Plate



**AWA (x1)\***  
Lock Bracket



**AVP (x2)\***  
Wheel Spacing Bracket

# SEC 1 AXLE/FRAME ASSEMBLY

## HARDWARE REQUIRED

Hardware is actual size (Unless indicated otherwise\*)




**AVQ (x2)**  
Retainer Ring



**AVR (x8)**  
1/4" Nylon Insert Nut




**AVS (x4)\***  
1/4" x 1 1/2" U-Bolt



**AVT (x2)\***  
U-Bolt Mounting Plate

## METAL PARTS REQUIRED


Parts are 5% of actual size (Unless indicated otherwise)



**AVM (x1)**  
Axle Weldment



**AVN (x1)**  
A-Frame



**AVK (x1)**  
Axle



**AVP (x2)\***  
Wheel Spacing Bracket

## OTHER PARTS REQUIRED

Parts are 5% of actual size (Unless indicated otherwise)



**AMU (x2)**  
Wheel

## TOOLS REQUIRED



**7/16" Socket Wrench**



**Needle-Nosed Pliers**



**Safety Glasses**




## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 1


1.



AVP (x2)



AVQ (x1)




### SEC

#### 1.1

### AXLE/FRAME ASSEMBLY



Insert **Axle (AVK)** through **Axle Weldment (AVM)** and slide one **Wheel Spacing Bracket (AVP)** over each end of Axle as shown.



### SEC

#### 1.2

Place Axle/Axle Weldment Assembly over **A-Frame (AVN)** as shown. Slide a **Wheel (AMU)** over the Axle, and use a pair of needle-nose pliers to secure the Wheel to the Axle with the **Retainer Ring (AVQ)** in the grooves at the ends of the Axle.






*Note: The valve stem goes toward the outside of the Garden Cart.*


1.



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE





SEC 1



SEC

1.3

Repeat **Step 1.2** for second Wheel.




**Note:** You may need to push on the other end of the Axle to expose the groove at the other end of the Axle. Since the bearings are sealed, it is not necessary to grease the bearings using the grease fitting.

SEC

1.4

Center the Axle on the A-Frame. Insert four (4) 1/4" x 1 1/2" U-Bolts (AVS) over the Axle and through the holes in the End Brackets, A-Frame, and the two (2) U-Bolt Mounting Plates (AVT). Secure with eight (8) 1/4" Nylon Insert Nuts (AVR).



**Note:** To avoid damaging the A-Frame, ensure you tighten all Nuts (AVR) evenly over each U-Bolt (AVS).



**Note:** Attach the two (2) U-Bolt Mounting Plates (AVT) to the two inner U-Bolts.


## SEC 2 TUB-TO-AXLE/FRAME ASSEMBLY

### HARDWARE REQUIRED

Hardware is actual size (Unless indicated otherwise\*)



**BJX (x1)**  
3/8" x 4 1/4" Hex Head Bolt



**AVV (x12)**  
5/16" x 1" Round Slotted Bolt



**ABE (x1)**  
3/8" x 4" Hex Head Bolt



**AVX (x12)**  
5/16" Threaded Hex Nut



**AWE (x1)**  
3/8" x 5" Carriage Bolt



**AVU (x10)**  
5/16" Flat Washer



**AVW (x12)**  
5/16" Lock Washer




**AWC (x2)**  
3/8" Plastic Flat Washer




**AAA (x2)**  
3/8" Nylock Nut



**AWB (x2)**  
3/8" x 1 1/2" Spacer



**AVY (x1)**  
Latch Spring




**AWD (x1)**  
Threaded Knob

## SEC 2 TUB-TO-AXLE/FRAME ASSEMBLY

### METAL PARTS REQUIRED


2. Parts are 5% of actual size (Unless indicated otherwise\*)




**AVO (x1)**  
Tongue




**BJW (x1)**  
Tongue Mounting Bracket



**AWA (x1)\***  
Lock Bracket




**AVZ (x1)\***  
Latch Handle



**AWF (x1)\***  
Backing Plate


### PLASTIC PARTS REQUIRED

Part is 5% of actual size



**AVJ (x1)**  
Tub

### TOOLS REQUIRED



Plain Screwdriver



9/16" Wrench (x2)



1/2" Wrench




Needle-Nosed Pliers



Safety Glasses



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE




1/2"



AVU (x8)



AVW (x8)




AVV (x8)



AVX (x8)

SEC 2



2.


### TWO ADULTS REQUIRED FOR THIS STEP

SEC

2.1




#### TUB-TO-FRAME ASSEMBLY

Turn **Tub (AVJ)** on its side and place A-Frame Assembly against Tub as shown. Secure A-Frame Assembly to Tub using eight (8) 5/16" x 1" Round Slotted Bolts (AVV), eight (8) 5/16" Flat Washers (AVU), eight (8) 5/16" Lock Washers (AVW), and eight (8) 5/16" Threaded Hex Nuts (AVX).






## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

**SEC 2****2.****1/2"****AVU (x2)****AVW (x2)****AVX (x2)****AVV (x2)****SEC****2.2**

Rotate the Axle Weldment away from the Tub. Place the **Lock Bracket (AWA)** over the two holes towards the front of the bottom of the Tub as shown. Lightly secure with two (2) **5/16" x 1" Round Slotted Bolts (AVV)**, two (2) **5/16" Flat Washers (AVU)**, two (2) **5/16" Lock Washers (AVW)**, and two (2) **5/16" Threaded Hex Nuts (AVX)**.



**Note:** Do not tighten Nuts yet.



## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE




1/2"



**NO HARDWARE REQUIRED FOR THIS STEP**

SEC 2




2.

SEC

2.3

Turn the Axle Weldment so it sets against the Lock Bracket. Reposition the Lock Bracket if necessary. Tighten the 5/16" threaded Hex Nuts (AVX).






## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE

SEC 2


2.



AVY (x1)





AVZ (x1)



SEC


2.4

Insert the **Latch Spring (AVY)** in the hole at the end of the **Axle Weldment** and through the hole in the **Latch Handle (AVZ)**.





## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE




9/16" (x2)

AAA (x1)




AWB (x2)



BJX (x1)



SEC 2




2.

SEC

2.5

Insert one (1) 3/8" x 1 1/2" **Spacer (AWB)** on each side of the Latch Handle as shown. Insert one (1) 3/8" x 4 1/4" **Hex Head Bolt (BJX)** and secure with one (1) 3/8" **Nylock Nut (AAA)**.





## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE


9/16" (x2)



AAA (x1)




AWC (x2)



ABE (x1)


SEC 2



SEC


2.6

Turn Yard Cart Assembly over. Place the **Tongue (AVO)** between the forks at the end of the Axle Weldment (as shown). Insert one (1) **3/8" Plastic Flat Washer (AWC)** on each side of the Tongue (between the forks of the Axle Weldment). Secure the Tongue with one (1) **3/8" x 4" Hex Head Bolt (ABE)** and one (1) **3/8" Nylock Nut (AAA)**.






## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE




1/2"



SEC 2


2.



SEC

2.7

Turn Yard Cart upright. On the inside of the Tub, place the **Backing Plate (AWF)** over the two holes towards the front of the Tub and insert two (2) **5/16" x 1" Round Slotted Bolts (AVV)** through the holes. Place the **Tongue Mounting Bracket (BJW)** over the Bolts and secure with two (2) **5/16" Lock Washers (AVW)**, and two (2) **5/16" Threaded Hex Nuts (AVX)**.




**Note:** Note the angle of the ends of the Tongue Mounting Bracket.

SEC

2.8

Rotate the Tongue upwards and insert one (1) **3/8" x 5" Carriage Bolt (AWE)** through the Tongue Mounting Bracket and Tongue and secure with one (1) **Threaded Knob (AWD)**.




### SEC 3 HANDLE BARS-TO-TONGUE ASSEMBLY

#### HARDWARE REQUIRED


Hardware is actual size

3.



#### METAL PARTS REQUIRED

Part is 5% of actual size



#### TOOLS REQUIRED



9/16" Wrench (x2)




Safety Glasses




## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE


SEC 3



AWE (x1)



AWD (x1)




3.

SEC


3.1

Place the **Handle Bars (AVL)** over the Tongue as shown. Insert one (1) **3/8" x 5" Carriage Bolt (AWE)** through the upper holes and secure with a **Threaded Knob (AWD)**.






## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE



9/16" (x2)




AWG (x1)

5"




AAA (x1)



AWH (x2)

SEC 3




3.

SEC

3.2


Insert two (2) **Handle Bar Spacers (AWH)** between the forks of the Handle Bars and the Tongue. Slide one (1) **3/8" x 5" Hex Head Bolt (AWG)** through the Handle Bar forks, Spacers and Tongue. Secure Handle Bars to Front Tongue with one (1) **3/8" Nylock Nut (AAA)**.





## TOOLS AND HARDWARE REQUIRED FOR THIS PAGE


SEC 3



AWI (x1)



AWJ (x1)




3.

SEC

3.3

Insert **Clevis Pin (AWI)** through the hole at the top of the Tongue and secure it with a **Cotter Key (AWJ)**.




## SEC 4 YARD CART DEPLOYMENT

### YARD CART DEPLOYMENT

#### SEC

#### 4.1


Unscrew Front Tongue/Handle Bar Assembly and remove Carriage Bolt.



#### SEC

#### 4.2

Rotate Front Tongue/Handle Bar Assembly down until holes at the bottom of the Front Tongue line up with holes in Axle Weldment, and re-insert the Carriage Bolt through holes in Tongue and Axle Weldment and secure with Threaded Knob.



### WARNING


Watch for pinch points as serious injury could occur.

## YARD CART DEPLOYMENT

### SEC

#### 4.3


Unscrew Handle Bar Assembly and remove Carriage Bolt.



### SEC

#### 4.4

Rotate Handle Bar Assembly backwards until holes in forks line up with holes in Tongue and re-insert the Carriage Bolt through holes in forks and Tongues and secure with Threaded Knob.




## YARD CART DEPLOYMENT

### SEC

#### 4.5


Connect the Yard Cart to the Tow Vehicle by inserting the Clevis Pin through the Tongue and Tow Vehicle. Secure the Yard Cart to the Tow Vehicle with the Cotter Key.



### SEC

#### 4.6

To unload contents of cart, hold Tub with one hand, pull back on the Latch Handle, and carefully tilt the Tub backwards.




## SEC 5 BUILD WALL EXTENSIONS

### BUILD WALL EXTENSIONS

#### SEC

#### 5.1

You can insert standard 1" x 2" (about 3/4" x 1 1/2") boards into the six slots on the sides of the Tub to extend the walls of the Yard Cart and hold a higher stack of debris.



5.

#### WARNING

To avoid serious injuries:

- Do not ride in or on cart.
- Do not exceed 650 lbs.
- Reduce load on hills or slippery surfaces.
- Do not exceed 10 mph.
- Do not fill gas can while gas can is in garden cart.

#### ADVERTENCIA

Para evitar lesiones graves:

- No transportar personas dentro o en la carretilla.
- No exceder los 1433 Kg (650 lbs).
- Reducir la carga de la carretilla en colinas o superficies resbaladizas.
- No exceder los 16,1 Km/h (10 mph).
- No llenar los botes de gas mientras que estén en la carretilla.

#### AVERTISSEMENT

Pour éviter les blessures graves :

- Ne pas transporter des personnes dans ou sur la charrette.
- Ne pas dépasser 1433 Kg (650 lbs).
- Réduire la charge sur les côtes ou les surfaces glissantes.
- Ne pas dépasser 16,1 Km/h (10 mph).
- Ne pas remplir les bidons d'essence pendant qu'ils sont dans la charrette.

#1034754

## WARRANTY INFORMATION

### 5-YEAR LIMITED FACTORY WARRANTY

**THE MANUFACTURER RESERVES THE RIGHT TO MAKE SUBSTITUTIONS TO WARRANTY CLAIMS IF PARTS ARE UNAVAILABLE OR OBSOLETE.**

1. Lifetime yard carts are warranted to the original purchaser to be free from defects in material and workmanship for a period of five years from the date of original retail purchase. The word "defects" is defined as imperfections that impair the use of the product. Defects resulting from misuse, abuse or negligence will void this warranty. This warranty does not cover defects due to improper installation, alteration, or accident. This warranty does not cover damage caused by vandalism, rusting, "acts of nature" or any other event beyond the control of the manufacturer.
2. The tires, wheels, and axle included with the yard cart are not covered by this 5 year limited factory warranty, but are covered by separate 1 year warranty.
3. This warranty is nontransferable and is expressly limited to the repair or replacement of part(s) which may be determined upon inspection by the manufacturer to be defective in material or workmanship. Shipping charges to and from the factory as well as labor costs are not covered and are the responsibility of the purchaser.
4. This warranty does not cover scratching or scuffing of the product that may result from normal usage. In addition, defects resulting from intentional damage, negligence, unreasonable use, improper loading or overloading, installation of improper equipment, or improper towing will void this warranty.
5. Liability for incidental or consequential damages is excluded to the extent permitted by law. While every attempt is made to embody the highest degree of safety in the yard cart, freedom from injury cannot be guaranteed. The user assumes all risk of injury resulting from the use of this product. All merchandise is sold on this condition, and no representative of the company may waive or change this policy.
6. This warranty is expressly in lieu of all other warranties, expressed or implied, including warranties of merchantability or fitness for use. Neither Lifetime Products, Inc. nor any representative assumes any other liability in connection with this product.

**ALL WARRANTY CLAIMS MUST BE ACCOMPANIED BY A SALES RECEIPT.**

**REPORT PRODUCT DEFECTS IN WRITING TO:**

Lifetime Products, Inc., PO Box 160010 Clearfield, UT 84016-0010  
or call (800) 225-3865 M-F 7 a.m. to 5 p.m. MST.

**Please include your dated sales receipt and photographs of damaged parts.**

**To register the product, visit our Web site at [www.lifetime.com](http://www.lifetime.com)**



[www.lifetime.com](http://www.lifetime.com)

©2004 Lifetime Products, Inc.

PO Box 160010 • Freeport Center, Bldg. D-11 Clearfield, Utah 84016-0010  
T: 800-225-3865 • F: 801-728-1907

**ENHANCE YOUR LIFETIME® PURCHASE BY ADDING ACCESSORIES OR OTHER GREAT PRODUCTS**

---

*To purchase accessories or other Lifetime Products, visit us at:*

***www.lifetime.com***

***Or call: 1-800-424-3865***

---

